GATE CLOSING GAS STRUT


G Top quality gate closing strut, ideal for closing gates

G Using the unique adjustable brackets the force this

 \mathbf{G} No need to release gas, simply move the strut along the slots in the brackets to adjust the force exerted. The force can be increased again by moving the strut

G The adjustable brackets also make the installation

closer exerts can be altered as required.



SPECIFICATION

GSB

SHEET

fitting it to the gate.

up to 80kg (175lb).


further than the gate hinge.


PRODUCT DETAILS Product code: | **Description:** GSB Weld on gate closing strut GSB **GSBW** Screw fix gate closing strut 80kg (175lb) Max gate weight: 2500mm (8ft 2.43") high x 1200mm (3ft 11") wide Max gate size: End fittings: M10 elbow joints Fitted with steel rod protection tube. GSBW Finish: **Black finish** 792mm (9-3/16") Center to center: 240mm (9-29/64") Stroke length: 300N Force:

INSTALLATION

- 1. Fix the brackets supplied in position relative to the center of the hinge as shown. WARNING! Do not weld the brackets with closer fitted, this could damage the seals.
- 2. Close the gate and secure the strut to the slotted bracket and the long bracket using the shakeproof washers and nuts provided. Washer positions are as shown. To increase or decrease the force exerted on the gate, reposition the strut on the long bracket as required.
- IMPORTANT: if the gate can be opened more than 3. 90° there is potential for the strut to be damaged. We recommend fitting a stop to prevent this.

MAINTENANCE: The piston rod is protected by a steel cover tube. The piston rod should not be lubricated or damaged in any way, as this will reduce the life of the seals. Periodically lubricate the ball joints with a light oil and clean the surface of the gas strut with a damp cloth.





GATEMASTER

VISIT GATEMASTERLOCKS.COM FOR MORE INFORMATION

+44 (0)1243 558 580